

# **SEMI AUTO WASHING MACHINE**





### **WASH PROGRAM**

Select "GENTLE" or "NORMAL" for washing and rinsing.



### **WASH TIMER**

Use to select the desired time for washing or rinsing.



### **WATER INLET & WATER GUIDE KNOB**

Insert the water inlet hose to the water inlet to feed water into the wash tub or the spin tub.



### **WASH SELECTOR**

Select "WASH/RINSE" washing and rinsing, and "DRAIN" to drain the water.



#### **SPIN TIMER**

Use to select the desired time for spinning.

## **SPECIFICATIONS**

Model	EST1416	EST1216	EST1016	EST7015
Wash capacity (kg)	14kg	12kg	10kg	7kg
Spin capacity (kg)	7.5kg	7.5kg	6.5kg	5.6kg
Outer cabinet	Plastic	Plastic	Plastic	Plastic
Rate voltage	220 - 240V	220 - 240V	220 - 240V	220 - 240V
Rated wash power	500W	550W	420W	340W
Rate spin power	210W	230W	190W	160W
Net weight (kg)	28	28.5	23	19
Net dimensions (mm) (WxHxD)	930 × 1045 x 545	890 × 1045 × 535	838 × 990 × 490	738 x 941 x 440
Wash program	3 courses washing programme - Normal, Gentle, Soak wash			

Design and specification as current as of April 2017, but are subject to change without prior notice. Actual colours may differ slightly from colours in this catalogue.



